

HAVIT H628BT WIRELESS FOLDABLE HEADPHONES USER MANUAL	Packing list: Headphones*1 User Manual*1 3.5mm audio cable*1 Charging Cable*1 Certificate of quality*1 1	Production structure 1. Power button/Mode button 2. Multi-function button(MFB) 3. V+/Next track 4. V-/Previous track 5. LED indicator 6. AUX in 7. Type-C charging port 8. TF card slot 2	Bluetooth pairing Follow the steps(ensure Bluetooth function of music player device is on and able to be search) 1.Power on:Press power button for 2 seconds to turn on the headphones.The LED indicator stay blue light, then red and blue light alternately flash, the headphones enter the pairing status. (Note: The headphones can automatically enter pairing status after power on if there is no re-connection. As the headphone can automatically reconnect with the last device that you had paired. To re-connect, you just need to turn it on.) 2.Activate the Bluetooth function and search for "HAVIT H628BT" referring to your phone instructions. 3.Manually click "HAVIT H628BT" to connect. Once paring successfully, the blue light blinks once every 5 seconds. Answering incoming calls Click MFB once to answer incoming calls. Tip: Since some mobile phones default to answer calls via their own receiver, please 3
refer to the instructions of your phone and set on your phone. End the current call Click MFB once to end the current call. Reject incoming calls Long press MFB for 2 seconds when there comes a call. Last number redial Double press MFB to redial the last calling number. Music control 1.Play/Pause: Short press MFB ; 2.NEXT: Long press V+ to select the next track; 3.PREV: Long press V- to select the previous song; 4.VOL +: Short press V+ to increase volume; 5. VOL -: Short press V- to decrease volume. Wired mode: Dual 3.5mm Audio Cable connecting To Audio Jack 1. Plug and play: Connecting the headphones to a music player with the provided dual 4	3.5mm audio cable, the headphones can be used as wired headphones without starting. 2. In this mode, you can't use any function of the headphones, including pause playback, volume adjustment, microphone and so on. Insert a TF card Please make sure that the TF card is inserted correctly to the slot before use. Click power button can switch to the TF card mode. FM mode Click the power button to select FM mode. In this mode: long press the MFB to scan and store FM channels. To charge the headphones 1.As product is built-in non-removable and rechargeable battery, PLS use the provided Type-c charging cable to charge; 2.Fully charge the product before the first use; 3.The LED indicator is red when charging.After fully charged, the LED indicator turn solid blue. Notes a. Please choose the charger that is certified 5	by the regular manufacturer. b.The battery performance may decrease as repeating charging and using the product. It's a normal phenomenon for all rechargeable batteries. Specification: Bluetooth Version: V5.3 Headphones Battery: 200mAh Play Time: 10H(60% Vol.) Charging Time: About 1.5H Input Voltage / Current: DC 5V/200mA Warnings 1. Please follow the instruction to operate 2. Please charge the headphones with input power below 1A, in order to protect the battery; 3. Please store or use the headphones in a normal temperature environment. 4. Please keep the headphones from heat source, such as radiators, hot air regulators, stoves, or other heat generating instruments. As it is not anti-high temperature. 5. Don't jam the ports of the headphones, such as charger port, LED port and 6	microphone etc.. 6. In order to protect your hearing and extend the headphones service life, it is not recommended to adjust the volume to the maximum level for a long time. 7. Whatever reasons damage the headphones, please feel free to contact our after-sales staff in time rather than repair by yourself. Otherwise, you will accept without after-sales service. 7